



Application Guide



Step 1

- * Start by finding where the orange release paper joins the clear plastic film on the back of the Tack-Mat.
- * Peel back 3 to 4 feet of the release paper. Fold this section back underneath the Tack-Mat roll.



Step 2

- * Making sure to properly align the roll to ensure a straight application.
- * Attach the tack side to the surface, press in the Tack-Mat firmly.



Step 3

- * Working in pairs, roll out the Tack-Mat by evenly pulling the release paper and firmly smoothing out contact with the surface with a dry paint roller.



Step 4

- * Once one row is completed, unpeel 8-10 feet of the release paper and align the edge with the white overlap edge of the first row.
- * Keep Tack-Mat pulled tight, place overlap down first, smoothing Mat onto surface.
- * The Tack-Mat will stick to the white edge. In high-wind areas, the use of a spray adhesive maybe needed.



Step 5

- * Continue the process until the entire area is covered.
- * The Skudo Tack-Mat can be lifted for inspection or re-adjusted as needed at any time.
- * Your surface is now protected.



Stairs

- * Skudo Tack-Mats are a great solution for protecting stairs on any type (Concrete, Marble, Tile, Hardwood or Carpet)
- * Start from the bottom and pull the release paper up while moving the roll up the stairs - ensure to push/press the Tack-Mat down onto all the treads and risers.

For more information please contact us or visit our website

www.SkudoUSA.com

1-888-Skudo11
(1-888-758-3611)

info@SkudoUSA.com